

Litter Conveyor

SERIAL # _____

WORK ORDER # _____

Table of Contents

Chandler Equipment Co. Personnel.....Page 1

Warranty Information.....Page 2, 3, 4

Section - Safety

Warning Label Page S-1

Safety Precautions Page S-2

Section 1 - Basic Information

Discharge Height Page 1-1

Caution Page 1-2

Hydraulic Drive System Requirements Page 1-3

Conveyor Pressure Settings Page 1-4

How to Install Pressure Gauge Page 1-5

How to Adjust Relief Pressure Page 1-6

Section 2 - Hydraulic Drive System

Hydraulic System – Litter Conveyor Page 2-1

Hydraulic System Parts List Page 2-2

Hydraulic Filter Assembly Page 2-3

Hydraulic Valve (Prince - RD5100 Series) Page 2-4

Hydraulic Valve - Relief Pressure Adjustment Page 2-5

Hydraulic Valve - Spring Center Spool Attachment	Page	2-6
Hydraulic Cylinder - Seal Replacement/ Parts List	Page	2-7
Vickers V10 - Single Pump Breakdown	Page	2-8
Flow Control Valve	Page	2-9
Flow Control Valve Breakdown	Page	2-10
Pump Mount Breakdown and Parts List	Page	2-11
Conveyor Chain Components - Breakdown	Page	2-12
Conveyor Chain Components - Parts List	Page	2-13
Single Aluminum Gear Case - Breakdown and Parts List	Page	2-14
Conveyor Motor MB-18 Breakdown	Page	2-15

Section 3 - Axle Assembly

Complete Axle Assembly	Page	3-1
Complete Axle Assembly Parts List	Page	3-2

Section 4 - Operation & Maintenance

Basic Operation of Litter Conveyor	Page	4-1
Maintenance	Page	4-2

Section 5 - Honda GX630 - Gas Engine Manual

Honda GX630 – Gas Engine Manual (English Only)	19 Pages
--	----------

Chandler Equipment Company Personnel

Bill Chandler **Chief Executive Officer**
Advertising & Marketing
Dealer / Distributor Arrangements

Brannon Chandler **General Manager**
Production & Scheduling
Warranty, Sales and Service

Andrea Thompson **Administrative Assistant**

Lisa Johnson **Accounts Receivable**
Collections

Michael Sosebee **Sales Manager**

Gene Dye **Outside Sales**
Mid-South Regional Sales Manager

Dan McCorvey **Outside Sales**
Southeast Regional Sales Manager

Richard Wray **Outside Sales**
Western Regional Sales Manager

Matt Farmer **Inside Sales**

Andrew Weinman **Precision Ag Products**
Bryan Tullis **Equipment Service**

Tim Leach **Parts & Service**

Dylan Berta **Parts & Service**

Warranty Policy

A) Standard Warranty:

Chandler Equipment Company warrants that equipment manufactured by Chandler Equipment Company, under normal conditions of use and service, shall be free from material defects due to faulty manufacturing for the period listed below.

- a. Poultry Litter Spreaders and Conveyors – Six (6) Months
- b. Fertilizer and Lime Pull Type Spreader – Six (6) Months
- c. Fertilizer Tenders (Trailer or Truck Mounted) – Six (6) Months
- d. Fertilizer and Lime Chassis Mounted Spreaders – One (1) Year

This warranty period is from the date of delivery to the original owner.

(Warranty period is on equipment built after July 1, 2012)

B) Warranty Approval:

- a. Any and All warranty claims must be approved in writing by Chandler Equipment Company prior to any work being done.
- b. **ANY WORK DONE WITHOUT PRIOR WRITTEN APPROVAL WILL NOT BE COVERED UNDER WARRANTY AND THE CUSTOMER / DEALER WILL BE RESPONSIBLE FOR ALL COST.**

C) Warranty Claim Forms: (Dealer Only)

- a. Warranty claim form / forms will be supplied to Dealer upon request.
- b. Warranty claim forms are available in 2 part paper form or in an electronic format.
- c. All warranty claims must include serial number, date of purchase, customer name and date of sale to original owner. (See attached warranty claim instructions for guidelines on filling out warranty claim form)
- d. Improperly filed or misleading information on warranty claims shall result in warranty claim being denied.
- e. **ALL WARRANTY CLAIMS MUST BE FAXED TO (770) 535-1265.**

D) Labor and Repair Cost: (Dealers Only)

- a. Labor for any repairs must be approved prior to any work being done.
- b. Labor rate (per hour) will be determined by Chandler Equipment Company, See Chandler Labor Rate List.
- c. Also Chandler Equipment Company retains the right to adjust any and all warranty claims.

E) Dealer Responsibility:

- a. Dealer shall be first line in all communications with the customer.
- b. Dealer shall also maintain good and open communications between the customer and Chandler Equipment in order to resolve warranty issues.
- c. Dealer shall be responsible for informing the customer of operating procedures, safety precautions and normal maintenance to help avoid any warranty issues.

- d. Promptly inform Chandler Equipment of any possible warranty issues.
- e. Dealer is responsible for making every effort to resolve warranty issues in a timely manner.
- f. Notify Chandler Equipment on any possible non-warranty issues, such as any modification made to equipment.

F) Original Chandler Genuine Parts:

- a. Chandler Equipment Company will only warranty equipment that uses Chandler Genuine Parts. Any equipment that is sold by a dealer with parts other than Original Chandler Genuine parts shall Void Any and All warranties

G) Replacement Parts Shipping:

- a. Chandler Equipment Company shall send Chandler Genuine Parts for warranty replacement. Chandler Equipment shall NOT warranty any part or parts replaced by the Customer/Dealer that are not Chandler Genuine Parts.
- b. Cost of any part or parts that are replaced by the Customer / Dealer that are not Chandler Genuine Parts shall be the sole responsibility of the Customer / Dealer.
All replacement parts covered under warranty will be shipped via regular UPS. The cost of any parts shipped **UPS-Next Day Air** will be the sole responsibility of the Customer/Dealer.

H) Parts Returns:

- a. All parts replaced under warranty will be returned to Chandler Equipment Company within 20 days of replacement for warranty evaluation. All parts returned for warranty evaluation must be in its original state free of modifications. Any modifications will result in the warranty claim being denied and the part or parts returned back to the customer/dealer.
- b. Any hydraulic components returned must be assembled (in original state) and with the ports plugged to prevent any contamination. Any hydraulic component that has been disassembled will VOID the warranty claim and the part or parts returned back to the customer/dealer.
- c. All Returned Parts for warranty evaluation must be clearly tagged with the following information.
 - I. RMA number
 - II. Customer or Dealer Name, address, phone number and contact person
 - III. Equipment serial number
 - IV. Complete description of problem

I) Misuse or Improper Installation:

- a. Any equipment, parts, or components that have been damaged by improper installation or misuse will **NOT** be covered under this warranty.
- b. Chandler Equipment accepts no responsibility or liability of any kind due to improper installation of equipment or parts on any product manufactured by Chandler Equipment Company. This includes, but is not limited to, any damages to personal property, crops, or any other equipment.

J) Incomplete Equipment and Dealer Add-Ons:

- a. Chandler Equipment does not warrant any equipment sold **INCOMPLETE**. This includes (but is not limited to) axles, tires, any hydraulic components or paint.
- b. Any Non Genuine Chandler Parts that are installed as aftermarket add-ons by anyone not approved in writing by Chandler Equipment Company shall **VOID ALL WARRANTIES**.
- c. Chandler Equipment Company accepts no responsibility, nor shall warrant any equipment or any component that is damaged due to any type Control System not sold and installed by Chandler Equipment Company.

K) Items Not Covered Under this Warranty:

- a. Any equipment that has been modified from its original state.
- b. Any equipment used for any other purpose that what it was originally designed for.
- c. Any travel time, cleaning of equipment, unloading of material, or towing.
- d. Any cost of materials that have been applied improperly due to the lack of customer / dealer not following proper operating instructions.

Litter Conveyor Safety



WARNING!

- **DO NOT CLIMB ON CONVEYOR FOR ANY REASON**
- **BE CAREFUL WHEN RAISING OR LOWERING CONVEYOR**
- **LOWER CONVEYOR BEFORE TRANSPORTING**
- **SHUT OFF ENGINE BEFORE REPAIRING CONVEYOR**

THINK SAFETY!


Safety Precautions

- 1) Be sure all guards or other safety devices, and decals are in place and functioning properly.
- 2) Stay away from moving parts when conveyor is in operation.
- 3) Check lug nuts daily; refer to Section 3 of this manual for torque specifications.
- 4) Maintain proper tire pressure, according to Section 3 of this manual.
- 5) If conveyor becomes clogged, turn off engine before entering hopper or cleaning the conveyor.
- 6) Be sure to fully lower conveyor before transporting.
- 7) While transporting check for clearance of low underpasses (i.e. bridges, power lines, etc.)

Section 1

Basic Information

Discharge Height



A= Discharge Height (measured 24" from end)

B= Overall Height

C= Loading Height of Hopper

	<u>A</u>	<u>B</u>	<u>C</u>
Raised	14' 3"	16' 6"	5'
Lowered	10' 1"	12' 1"	5' 1"



Caution:

While operating a Chandler Equipment Co. Litter Conveyor, make sure that the conveyor has sufficient clearance when it is fully raised.

When transporting a Chandler Equipment Co. Litter Conveyor, make sure that the conveyor is completely lowered and resting on the stops. Also make sure that the jacks are fully raised, and all safety pins on the hitch assembly are in place.

1) Hydraulic Drive System Requirements

The Chandler Litter Conveyor comes standard with a Honda 18 H.P. V-Twin gasoline engine coupled to a Vickers V-10 vane style hydraulic pump. The conveyor requires approximately 15 GPM @ 2200 PSI.

- GPM (Gallons Per Minute)
- PSI (Pounds per Square Inch)

Hydraulic Oil Requirements

Please use:

Oil Type – 46 Series (10 to 15 W)

2) Conveyor Pressure Settings

1) Checking Pressure

- a) Run unit empty at ordinary operating speed for approximately 10 minutes. This allows oil to reach operating temperatures.
- b) Shut engine off and install pressure gauge into “CF” port on flow control valve. (Refer to hydraulic flow control valve drawing – **page 1-5**).
- c) Restart engine with flow control valve on 0.
- d) Slowly open flow control valve to 10 while watching pressure gauge
- e) Pressure gauge should read 2200 psi. If not adjust pressure as outlined below.


Caution: When checking pressure, never allow conveyor to run over a few seconds with pump running and gauge installed in line. Once pressure reading is taken shut off engine **immediately.**

2) Adjusting Hydraulic Flow Control Valve Pressure: (Refer to **page 1-6**)


- a) Remove cap nut on flow control valve (located on top of valve).
- b) Using a 5/16 Allen wrench turn adjustment screw “IN” to increase pressure or “OUT” to decrease pressure.
- c) Turn adjustment screw one half turn, then check pressure setting as outlined above.
- d) Continue this procedure until pressure gauge reads **2200 psi.**

NOTE: If unable to obtain 2200 psi contact your local dealer or Chandler Equipment Service Department at 1-800-243-3319.

3) How to Install Pressure Gauge



4) How to Adjust Relief Pressure




- 1) Remove cap nut on flow control valve (located on top of valve).
- 2) Using a 5/16 Allen wrench turn adjustment screw “IN” (Clockwise) to increase pressure or “OUT” (Counter Clockwise) to decrease pressure.
- 3) Turn adjustment screw one half turn, then check pressure setting as outlined above.
- 4) Continue this procedure until pressure gauge reads **2200 psi**.

Section 2

Hydraulic System

Hydraulic System Litter Conveyor




Hydraulic System Parts List

Ref.	Part #	Description	QTY
A	400-R-112	Vickers V10 Pump	1
B	400-1-314	¾" Splitter Valve 2:1 Ratio	1
C	400-1-335	Valve for Cylinder (RD516CB5A4B1)	1
D	400-1-313	Flow Control Valve (FCR-51-75-125AE)	1
E	400-1-338	LOD-50 Check Valve	1
F	400-1-296	2.5" x 20" Cylinder	2
G	400-R-106	MB180102 Torque Motor	1
H	400-C-214	18gal Hydraulic Tank	1
*	400-C-216	Hydraulic Oil (46 Series)	18 Gal
I	400-1-317	Hydraulic Tank Breather Cap	1
J	400-1-318	Filter Assembly - Small	1
*	400-1-319	Filter Element - Small	1
*	400-1-322	Oil Site Gauge	1

* Not Shown


Hydraulic Filter Assembly



- 1) Filter Element 400-1-319**
2) Filter Head 400-1-318 (when ordering this part # items 3 & 4 are included)

Cross Reference #’s: WIX Filter# 51551 Napa Gold Filter# 1551 Baldwin# BT839-10

Hydraulic Valve (Prince – RD5100 Series)



RD5100 1 SPOOL MONO-BLOCK VALVE

ITEM	QTY	PART NO.	DESCRIPTION
1	1		1 SPOOL VALVE BODY
2	1	SEE NOTE 1	SPOOL
3	2	670500010	SPOOL SEAL BACK-UP
4	2	240000213	213 O-RING
5	1	240000116	116 O-RING
6	1	240019015	015 BACK-UP
7	1	240000015	015 O-RING
8	1	240000916	916 O-RING
9	1	240000908	908 O-RING
10	1	670100001	LOAD CHECK POPPET
11	1	670300007	LOAD CHECK SPRING
12	1	671600001	LOAD CHECK PLUG


These are matched parts and are not sold separately.

SEAL KIT 660551001 (PLUS OTHERS)

LOAD CHECK KIT, NO. 660150015

NOTE: Chandler Equipment only stocks a limited selection of replacement parts for this style valve. Please check with your local dealer or our Parts Department for availability of replacement parts.

Hydraulic Valve – Relief Pressure Adjustment




RD5000 RELIEF CARTRIDGES

ITEM	QTY	PART NO. (UNTESTED)	DESCRIPTION	PRESET CARTRIDGE	SETTING
1	1	660250006	NO RELIEF PLUG (OPTION 1)		
2	1	660250005	SHIM ADJUSTABLE RELIEF 500-1500 (OPTION 2)	RV-ONL	1000 PSI
3	1	660250004	SHIM ADJUSTABLE RELIEF 1500-3000 (OPTION 3)	RV-ONH	2000 PSI
4	1	660250003	ADJUSTABLE RELIEF 500-1500 (OPTION 4)	RV-OL	1000 PSI
5	1	660250002	ADJUSTABLE RELIEF 1500-3000 (OPTION 5)	RV-OH	2000 PSI
		672000101	.015 SHIM		
		672000102	.033 SHIM		
		672000103	.060 SHIM		

NOTE: Refer to relief cartridges 4 and 5 for relief pressure adjustment.

NOTE: Chandler Equipment only stocks a limited selection of replacement parts for this style valve. Please check with your local dealer or our Parts Department for availability of replacement parts.

Hydraulic Valve – Spring Center Spool Attachment



RD5000 SPRING CENTER SPOOL ATTACHMENT

ITEM	QTY	PART NO.	DESCRIPTION
1	1	670500003	RETAINER PLATE
2	1	671400001	STOP CUP (INNER)
3	1	670300001	CENTERING SPRING*
4	1	671400011	STOP CUP (OUTER)
5	1	670500004	WASHER
6	1	170003007	SOCKET HD. CAP SCREW
7	1	670500005	END CAP
8	4	170003008	SOCKET HD. CAP SCREW

SPRING CENTER KIT NO. 660150001

*STANDARD CENTERING SPRING CAN BE REPLACED WITH MEDIUM HEAVY SPRING PART NO. 670300047 OR HEAVY SPRING 670300043.

NOTE: Chandler Equipment only stocks a limited selection of replacement parts for this style valve. Please check with your local dealer our Parts Department for availability of replacement parts.

Hydraulic Cylinder

Seal Replacement Guide for Tie Rod Cylinders

1. Remove all port obstructions and make sure all oil has been drained from the cylinder.
2. Clamp rod end mount (6) in vise and fully extend cylinder. If there is no mount. Protect rod threads while clamping.
3. Remove the 4 tie bolt nuts (7) on gland end and un-thread the bolts from the base end.
4. Remove the base (5) and slip the tube off of the gland (3) if necessary, gently tap the gland and base with a rubber Mallet to loosen.
5. Remove piston nut (13) and slip piston (4) and gland off rod (1) drive piston off with gland. Remove gland from the piston end of the rod.
6. Remove old seals from gland, piston and base.
7. Wash and check all parts for excessive wear or obvious defect which might interfere with operation.
8. Lubricate all new seals with STP or heavy oil before assembling.
9. Install new seals (15) (16) (18) & (19) in gland taking care to position the I. D. U-cup (15) toward the pressure as shown in Figure 1.
10. Install piston seal & energizer (17) and internal o-ring (20) into piston.
11. Install o-ring (18) and back-up (19) on the base. See Figure 2 for o-ring/back-up orientation.
12. With a twisting motion push gland onto rod from the piston end.
13. Torque piston nut (13) according to Table #1. Lube gland & piston seals.
14. Slide tube over piston and onto gland. Replace base making sure parts are properly aligned to avoid cutting o-rings.
15. Replace tie rods and torque nuts as specified in Table #1. Use a cross-tightening pattern.
16. Hand stroke cylinder to check for binding.
17. Your cylinder is now ready for operation.




Figure 2




Figure 1




TABLE #1 (Torque Guide)
on Reverse Side (Page 2)

LINE NUMBER	DESCRIPTION	QUANTITY
1	PISTON ROD	1
2	TUBE	1
3	GLAND(HEAD)	1
4	PISTON	1
5	BASE CLEVIS	1
6	ROD CLEVIS	1
7	TIE ROD	4
8	CLEVIS PIN	2
9	R-CLIP	4
10	PORT PLUG	3
11	CLEVIS BOLT	1
12	CLEVIS NUT	1
13	PISTON NUT	1
14	TIE ROD NUT	4
15	ROD SEAL	1
16	ROD WIPER	1
17	PISTON SEAL/ENERGIZER	1
18	ORING	2
19	ORING BACK-UP	2
20	PISTON INTERNAL ORING	1


THE USE AND RECEIPT OF THIS INFORMATION BY ANY RECIPIENT IS SUBJECT TO ALL LIMITATIONS AND RESTRICTIONS SET FORTH ON THE REVERSE SIDE (PAGE 2) OF THIS INFORMATION SHEET. IN NO INSTANCE DOES BAILEY OR THE CYLINDER MANUFACTURER ASSUME ANY RESPONSIBILITY FOR MALFUNCTIONS AND/OR DAMAGE TO EQUIPMENT OF ANY TYPE BASED ON ANY USE OF THIS INFORMATION.

Page 1

Parts Available from Chandler Equipment


Part #	Description	QTY
400-1-296	2.5" x 20" Hydraulic Cylinder	1
400-1-298A	Seal Kit - 2.5" Cylinder	1
400-1-293	Clevis Pin Kit	2

Vickers V10 – Single Pump



NOTE: Chandler Equipment only stocks a limited selection of replacement parts for this style pump. Please check with your local dealer or our Parts Department for availability of replacement parts not listed.


FCR – 51 - .75 Flow Control Valve



Note: Never bottom out adjustment screw. This could damage hydraulic system.



FC51 (Manual Flow Control and 0-30 gpm):



FC51 Parts List:


AP57	1/4-20 x 1/4 Set Screw
B5021	Handle
B5023	Snap Ring
B5024	O-ring 2-116
B504	Spring
B5058	3/16 x 7/8 Spring Pin
B5068	10-32 x 3/4 Thumb Screw

B5069	FC51 Dial Plate
C9A	Spool (Standard)
C9A-093	Spool (.093 Dash Pot)
C9A-2P	Spool (2 Port)
C9AS	Spool (.020 Dash Pot)
P1616	Nylon Seal Retainer
P1659	O-ring 2-019 90D

P1735	#12 SAE Plug
P1737	O-ring 2-021 90D
P1740	Identification Tag
XDC598	Spool (30 gpm)

FC Options:

FCR51 (BALL SPRING RELIEF)




FCR51 Parts List:

B5067	1/2 Steel Ball
P1658	Cap Nut
P1659	O-ring 2-019 90D
RL57A	Adjusting Screw
RL59A	Spring

Note: Casting not sold separately.
Replace with new valve.

Pump Mount Components




Pump Mount – Parts List

	Part #	Description	QTY
*	900-1-126B	18 Hp Honda Engine	1
*	400-C-350	18gal Gas Tank Kit w/Filter	1
A	400-R-112	Vickers V10 Pump	1
B	400-R-113	Pump Mount	1
C	1400-LJ-110	L100 3/4" - 3/16" Key (to Pump)	1
D	1400-LJ-104	L100 Sock	1
E	1400-LJ-101	L100 1" - 1/4" Key (to Engine)	1

* Not Shown


Hydraulic Drive Components



Hydraulic Drive Components – Parts List

	Part #	Description	QTY
A	100-R-1-01	Single Aluminum Gear Case	1
*	400-R-106	MB180102 Torque Motor	1
B	300-C-208	2" x 43" Rear Roller Shaft	1
C	UFC-211-32	UCF-211-32 Bearings Rear Roller	2
D	700-2-208	8 Tooth Cogs, for 2" Rear Roller	2
E	700-2-209	Weld-on Hubs, for 2" Rear Roller	2
F	500-2-210	D-667X Chain - Bars Every Other Link	65'
G	300-C-017	Front Roller Adjustment Rods	2
H	300-C-006	1-1/2" x 39" Front Roller Shaft	1
I	700-2-210	8 Tooth Cogs, for 1-1/2" Front Roller	2
J	UFC-208-24	UCF-208-24 Bearings Front Roller	2
		* Not Shown	

Single Aluminum Gear Case



<u>Description</u>	<u>Part #</u>
1) Single Gear Case (complete)	100-R-1-01
2) N/A	
3) N/A	
4) Pinion Gear	100-R-1-08
5) 67T Gear	100-R-1-07
6) Inboard Housing	100-R-1-09
7) Outboard Housing	100-R-1-10
8) Bearing - 50MM	100-R-1-03
9) Bearing - 25MM	100-R-1-04
10) Seal	100-R-1-05
11) Gasket - Single	100-R-1-06
12) Lock Washer	100-R-1-13
13) Cap screw 5/16"	100-R-1-14
14) Key - 1/2" (not shown)	100-R-1-11
15) Breather Plug (not shown)	100-R-1-12

*** When Ordering these parts have serial number available to insure proper parts

Conveyor Motor MB-18

Service Bulletin 050016

Issued February 2003

For TF (MB) and TG (ME) Torqmotor Seal Kits


SK000092 (Buna), SK000093 (Fluorocarbon),

SK000099 (Vespel Commutator Seal)

Reference Torqmotor Service Manual SM1512.



QTY	Item	Description	Buna P/N	Fluorocarbon P/N	Vespel P/N
1	17	Back up ring	028515	028515	028515
1	25	Back up washer	029118	029118	029118
1	3	Commutator Seal	032435	032435	032439
1	16	Shaft Seal	032817	032818	032817
6	4	Body Rings	032819	032820	032819
1	20	D&W Seal	478035	478035	478035
1		Bearing Lubricant	406018	406018	406018
1		Service Bulletin	050016	050016	050016




Section 3

Axle Assembly

Complete Axle Assembly

7,000 LB. HIGH SPEED AXLES
AXLE-HUB ASSY.



Axle Assembly Parts List

Ref.	Part Number	Part Description	QTY
A	800-8-101	7000 # High Speed Axle Assembly Complete	1
B	800-8-102	6 Bolt Hub Assy. (High Speed)	2
C	800-8-103	Spindle (High Speed)	2
D	800-8-104	Hub Only (High Speed)	2
E	800-8-105	Wheel Stud (High Speed)	12
F	800-8-106	Wheel Nut *Torque to 110-125 ft•lbs	12
G	800-8-107	Hub Cap (High Speed)	2
H	800-8-108	Cotter Pin	2
I	800-8-109	Slotted Nut (High Speed)	2
J	800-8-110	Washer (High Speed)	2
K	800-8-111	Outer Cone (High Speed)	2
L	800-8-112	Outer Race (High Speed)	2
M	800-8-113	Inner Race (High Speed)	2
N	800-8-114	Inner Cone (High Speed)	2
O	800-8-115	Oil Seal (High Speed)	2
*		245/65R16 Tire and Wheel	2
		* Not Shown	

Section 4

Operation & Maintenance

Basic Operation of Chandler Litter Conveyor

Basic Start Up:

1) Starting Gas Engine

- A) Follow engine manufactures supplied manual.

2) Adjusting Discharge Height

- A) Using the raise and lower valve (located in front of the engine) adjust conveyor to desired discharge height.

3) Starting Conveyor Chain

- A) Start Conveyor by moving the lever on the Flow Control Valve from 0.

4) Setting Engine Speed

- A) Using Engine Throttle Control set engine to desired run RPM.

5) Stopping Conveyor Chain

- A) Turn off flow control valve
- B) Lower conveyor to rest position
- C) Shut off engine

Maintenance

We are pleased you selected our equipment. We feel, as we are sure you do, that equipment must be maintained properly and made to last as long as possible. Outlined below are areas to be properly maintained.

1) Bearings:

Although Chandler conveyors come with factory pre-greased bearings, we recommend that you grease all bearings before using your conveyor.

Do NOT over grease bearings

Only one shot of grease per day.

Over greasing bearings will shorten the life of the bearings.

2) Hydraulic System:

Hydraulic filters should be changed every 120-200 hours or every four months.

Chandler conveyors come with 10-micron filters.

Use of filters not meeting these specifications could damage hydraulic components and void warranty.

Hydraulic Oil

Kendall Four Seasons

ISO VG 46

SAE 15W

Hydraulic Oil Level – Chandler conveyors come with oil level sight gauge.

Oil level should be to the top line on the gauge. Never let oil level get less than half way down on sight gauge.

3.) Fuel:

Chandler Equipment recommends using Ethanol-Free fuel in your Honda GX630 engine.

Please use fuel stabilizer when storing.

Section 5

Honda GX630 – Gas Engine

INTRODUCTION

Thank you for purchasing a Honda engine. We want to help you to get the best results from your new engine and to operate it safely. This manual contains information on how to do that please read it carefully before operating the engine. If a problem should arise or if you have any questions about your engine consult an authorized Honda servicing dealer.

All information in this publication is based on the latest product information available at the time of printing. Honda Motor Co. Ltd. reserves the right to make changes at any time without notice and without incurring any obligation. No part of this publication may be reproduced without written permission.

This manual should be considered a permanent part of the engine and should remain with the engine if resold.

Review the instructions provided with the equipment powered by this engine for any additional information regarding engine startup shutdown operation adjustments or any special maintenance instructions.


United States Puerto Rico and U.S. Virgin Islands
We suggest you read the warranty policy to fully understand its coverage and your responsibilities of ownership. The warranty policy is a separate document that should have been given to you by your dealer.

SAFETY MESSAGES


Your safety and the safety of others are very important. We have provided important safety messages in this manual and on the engine. Please read these messages carefully.

A safety message alerts you to potential hazards that could hurt you or others. Each safety message is preceded by a safety alert symbol and one of three words DANGER WARNING or CAUTION.


These signal words mean

**DANGER**

You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

**WARNING**

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

**CAUTION**

You CAN be HURT if you don't follow instructions.

Each message tells you what the hazard is what can happen and what you can do to avoid or reduce injury.

DAMAGE PREVENTION MESSAGES

You will also see other important messages that are preceded by the word NOTICE.

This word means

NOTICE


Your engine or other property can be damaged if you don't follow instructions.

The purpose of these messages is to help prevent damage to your engine other property or the environment.



HONDA

OWNER'S MANUAL
MANUEL DE L'UTILISATEUR
MANUAL DEL PROPIETARIO

GX630 · GX660 · GX690



Click here to save this manual to your computer.

**WARNING:**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer birth defects or other reproductive harm.

CONTENTS

INTRODUCTION.....	SPARK PLUG	0
SAFETY MESSAGES.....	SPARK ARRESTER	
SAFETY INFORMATION	HELPFUL TIPS &	
SAFETY LABEL LOCATION	SUGGESTIONS	
COMPONENT & CONTROL	STORING YOUR ENGINE....	
LOCATION	TRANSPORTING	
FEATURES	TAKING CARE OF	
BEFORE OPERATION	UNEXPECTED PROBLEMS	3
CHECKS	FUSE REPLACEMENT	3
OPERATION.....	TECHNICAL INFORMATION...	4
SAFE OPERATING	Serial Number Location	4
PRECAUTIONS	Battery Connections for	
STARTING THE ENGINE	Electric Starter	4
STOPPING THE ENGINE	Remote Control Linkage.....	
SETTING ENGINE SPEED.....	Carburetor Modifications for	
SERVICING YOUR ENGINE	High Altitude Operation	
THE IMPORTANCE OF	Emission Control System	
MAINTENANCE	Information	6
MAINTENANCE SAFETY.....	Air Index.....	
SAFETY PRECAUTIONS.....	Specifications	
MAINTENANCE	Tuneup Specifications.....	
SCHEDULE.....	Quick Reference	
REFUELING	Information	
ENGINE OIL.....	Wiring Diagrams	
Recommended Oil	CONSUMER INFORMATION..	9
Oil Level Check.....	WARRANTY AND	
Oil Change.....	DISTRIBUTOR DEALER	
OIL FILTER.....	LOCATOR INFORMATION ..	9
AIR CLEANER.....	CUSTOMER SERVICE	
Inspection	INFORMATION	9
Cleaning		

ENGLISH

FRANÇAIS


ESPAÑOL


SAFETY INFORMATION

- Understand the operation of all controls and learn how to stop the engine quickly in case of emergency. Make sure the operator receives adequate instruction before operating the equipment.
- Do not allow children to operate the engine. Keep children and pets away from the area of operation.
- Your engine's exhaust contains poisonous carbon monoxide. Do not run the engine without adequate ventilation and never run the engine indoors.
- The engine and exhaust become very hot during operation. Keep the engine at least 3 meter (3 feet) away from buildings and other equipment during operation. Keep flammable materials away and do not place anything on the engine while it is running.


SAFETY LABEL LOCATION

This label warns you of potential hazards that can cause serious injury. Read it carefully.
If the label comes off or becomes hard to read contact your Honda servicing dealer for replacement.



WARNING LABEL	For EU	Except EU
	attached to product	supplied with product
<div><p>⚠ WARNING</p><p>Gasoline is highly flammable and explosive. Turn engine off and let cool before refueling.</p><p>The engine emits toxic carbon monoxide. Do not run in an enclosed area.</p><p>Read Owner's Manual before operation.</p><p><small>Honda Motor Co., Ltd. MADE IN JAPAN</small></p></div>	supplied with product	attached to product
<div><p>⚠ ATTENTION</p><p>L'essence est très inflammable et explosive. Arrêtez le moteur et laissez refroidir avant de faire le plein d'essence.</p><p>Le moteur produit les vapeurs nocives de monoxyde de carbone. Ne pas utiliser dans un local clos.</p><p>Lire le manuel de propriétaire avant l'utilisation.</p><p><small>Honda Motor Co., Ltd. MADE IN JAPAN</small></p></div>	supplied with product	supplied with product

Honda factory equipped muffler.

MUFFLER CAUTION LABEL	
	not included
<div><p>⚠ CAUTION</p><p>HOT MUFFLER CAN BURN YOU. Stay away if engine has been running.</p></div>	supplied with product
<div><p>⚠ ATTENTION</p><p>L'ÉCHAPPEMENT CHAUD PEUT VOUS BRULER. S'ÉLOIGNER QUAND LE MOTEUR FONCTIONNE.</p></div>	supplied with product



Gasoline is highly flammable and explosive. Stop the engine and let cool before refueling.



The engine emits toxic poisonous carbon monoxide gas. Do not run in an enclosed area.





Read Owner's Manual before operation.



Hot muffler can burn you. Stay away if engine has been running.

COMPONENT & CONTROL LOCATION



FEATURES

Oil Alert® System (applicable types)


Oil Alert is a registered trademark in the United States™

The Oil Alert system is designed to prevent engine damage caused by an insufficient amount of oil in the crankcase. Before the oil level in the crankcase can fall below a safe limit the Oil Alert indicator (red) comes on and the Oil Alert system will automatically stop the engine (the engine switch will remain in the ON position).

If the engine stops and will not restart check the engine oil level (see page) before troubleshooting in other areas.

Hour Meter

After starting the engine the elapsed time of the engine in use will be count. It will not count the elapsed time of the engine operation by just turning the engine switch ON.



Fuel-cut Solenoid

The engine is equipped with a fuel-cut solenoid that allows fuel to flow to the carburetor main jet when the engine switch is in the ON or START position and stops the flow of fuel to the main jet when the engine switch is in the OFF position.

The engine must be connected to the battery to energize the fuel-cut solenoid allowing the engine to run. If the battery is disconnected fuel flow to the carburetor will stop.

BEFORE OPERATION CHECKS

IS YOUR ENGINE READY TO GO

For your safety and to maximize the service life of your equipment it is very important to take a few moments before you operate the engine to check its condition. Be sure to take care of any problem you find or have your servicing dealer correct it before you operate the engine.

⚠ WARNING

Improperly maintaining this engine or failure to correct a problem before operation can cause a malfunction in which you can be seriously hurt or killed.

Always perform a pre-operation inspection before each operation and correct any problem.

Before beginning your pre-operation checks be sure the engine is level and the engine switch is in the OFF position.

Always check the following items before you start the engine

Check the General Condition of the Engine

- Look around and underneath the engine for signs of oil or gasoline leaks.
 - Remove any excessive dirt or debris especially around the muffler.
3. Look for signs of damage.
4. Check that all shields and covers are in place and all nuts bolts and screws are tightened.

Check the Engine

- Check the fuel level. Starting with a full tank will help to eliminate or reduce operating interruptions for refueling.
 - Check the engine oil level (see page). Running the engine with a low oil level can cause engine damage.
- The Oil Alert system (applicable types) will automatically stop the engine before the oil level falls below safe limits. However to avoid the inconvenience of an unexpected shutdown always check the engine oil level before startup.
3. Check the air filter element (see page 9). A dirty air filter element will restrict air flow to the carburetor reducing engine performance.
4. Check the equipment powered by this engine.

Review the instructions provided with the equipment powered by this engine for any precautions and procedures that should be followed before engine startup.

OPERATION

SAFE OPERATING PRECAUTIONS

Before operating the engine for the first time please review the **SAFETY INFORMATION** section on page and the **BEFORE OPERATION CHECKS** on page 4 .

For your safety do not operate the engine in an enclosed area such as a garage. Your engine's exhaust contains poisonous carbon monoxide gas that can collect rapidly in an enclosed area and cause illness or death.

⚠ WARNING

Exhaust contains poisonous carbon monoxide gas that can build up to dangerous levels in closed areas. Breathing carbon monoxide can cause unconsciousness or death.


Never run the engine in a closed or even partly closed area where people may be present.

Review the instructions provided with the equipment powered by this engine for any safety precautions that should be observed with engine startup shutdown or operation.

Do not operate the engine on slopes greater than 10°.

STARTING THE ENGINE


- If the fuel tank is equipped with a valve be sure the fuel valve is in the OPEN or ON position before attempting to start the engine.
- To start a cold engine pull the choke knob out to the CLOSED position.



To restart a warm engine leave the choke knob in the OPEN position.


Some engine applications use a remote-mounted choke control rather than the engine-mounted choke knob shown here. Refer to the instructions provided by the equipment manufacturer.

3. Move the throttle lever away from the MIN. position about 3/4 of the way to and the MAX. position.



Some engine applications use a remote-mounted throttle control rather than the engine-mounted throttle lever shown here. Refer to the instructions provided by the equipment manufacturer.

4. Turn the engine switch to the ON position.



5. Operate the starter.


Turn the engine switch to the START position and hold it there until the engine starts.

If the engine fails to start within seconds release the engine switch and wait at least 30 seconds before operating the starter again.

NOTICE


Using the electric starter for more than 5 seconds at a time will overheat the starter motor and can damage it.

When the engine starts release the engine switch allowing it to return to the ON position.



6. Warm up the engine for 3 or 5 minutes.

If the choke knob is pulled to the CLOSED position to start the engine gradually push it to the OPEN position as the engine warms up.




STOPPING THE ENGINE


To stop the engine in an emergency simply turn the engine switch to the OFF position. Under normal conditions use the following procedure. Refer to the instructions provided by the equipment manufacturer.

1. Move the throttle lever to the MIN. position.

Some engine applications use a remote-mounted throttle control rather than the engine-mounted throttle lever shown here.



2. Turn the engine switch to the OFF position.




3. If the fuel tank is equipped with a valve turn the fuel valve to the CLOSED or OFF position.

SETTING ENGINE SPEED

Position the throttle lever for the desired engine speed.

Some engine applications use a remote-mounted throttle control rather than the engine-mounted throttle lever shown here. Refer to the instructions provided by the equipment manufacturer.

For engine speed recommendations refer to the instructions provided with the equipment powered by this engine.



Do not disconnect the battery from the engine while the engine is running. Disconnecting the battery causes the fuel-cut solenoid to shut off the flow of fuel to the carburetor main jet and the engine will stop.

SERVICING YOUR ENGINE

THE IMPORTANCE OF MAINTENANCE

Good maintenance is essential for safe, economical and trouble-free operation. It will also help reduce pollution.

⚠ WARNING

Improper maintenance or failure to correct a problem before operation can cause a malfunction in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To help you properly care for your engine, the following pages include a maintenance schedule, routine inspection procedures and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult or require special tools are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your engine under severe conditions, such as sustained high-load or high-temperature operation or use in unusually wet or dusty conditions, consult your Honda servicing dealer for recommendations applicable to your individual needs and use.

Maintenance, replacement or repair of the emission control devices and systems may be performed by any engine repair establishment or individual using parts that are "certified" to EPA standards.

MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

⚠ WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

SAFETY PRECAUTIONS

- Make sure the engine is off before you begin any maintenance or repairs. To prevent accidental startup disconnect the spark plug cap. This will eliminate several potential hazards
 - Carbon monoxide poisoning from engine exhaust. Operate outside away from open indoors or doors.
 - Burns from hot parts. Let the engine and exhaust system cool before touching.
 - Injury from moving parts. Do not run the engine unless instructed to do so.
- Read the instructions before you begin and make sure you have the tools and skills required.
- To reduce the possibility of fire or explosion be careful when working around gasoline. Use only a non-flammable solvent not gasoline to clean parts. Keep cigarettes sparks and flames away from all fuel related parts.

Remember that an authorized Honda servicing dealer knows your engine best and is fully equipped to maintain and repair it.

To ensure the best quality and reliability use only new Honda Genuine parts or their equivalents for repair and replacement.

MAINTENANCE SCHEDULE

REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval whichever comes first.		Each Use	First Month or 0 Hrs	Every 6 Months or 00 Hrs	Every Year or 300 Hrs	Every Years or 00 Hrs	Refer to Page
ITEM							
Engine oil	Check level	○					
	Change		○	○			
Engine oil filter	Replace		Every 00 Hrs.				9
Air cleaner	Check	○					9
	Clean			○ ()			9
	Replace					○ *	
Spark plug	Check-adjust			○			0
	Replace				○		
Spark arrester (applicable types)	Clean			○ (4)			
Idle speed	Check-adjust				○ ()		* *
Valve clearance	Check-adjust				○ ()		* *
Combustion chamber	Clean		After every 000 Hrs. ()				* *
Fuel filter	Replace				○ ()		* *
Fuel tube	Check		Every years (Replace if necessary) ()				* *

- * Replace the paper filter element only.
- * * Refer to the Shop Manual.
- () Service more frequently when used in dusty areas.
- () These items should be serviced by your Honda servicing dealer unless you have the proper tools and are mechanically proficient. Refer to the Honda shop manual for service procedures.
- (3) For commercial use log hours of operation to determine proper maintenance intervals.
- (4) In Europe and other countries where the machinery directive 006 4 EC is enforced this cleaning should be done by your servicing dealer.

Failure to follow this maintenance schedule could result in non-arratable failures.

REFUELING

Recommended Fuel

Unleaded gasoline		
U.S.		Pump octane rating 6 or higher
Except U.S.		Research octane rating 9 or higher
		Pump octane rating 6 or higher

This engine is certified to operate on unleaded gasoline with a pump octane rating of 6 or higher (a research octane rating of 9 or higher). Refuel in a well ventilated area with the engine stopped. If the engine has been running allow it to cool first. Never refuel the engine inside a building where gasoline fumes may reach flames or sparks. You may use unleaded gasoline containing no more than 10 ethanol (E 10) or methanol by volume. In addition methanol must contain cosolvents and corrosion inhibitors. Use of fuels with content of ethanol or methanol greater than shown above may cause starting and or performance problems. It may also damage metal rubber and plastic parts of the fuel system. Engine damage or performance problems that result from using a fuel with percentages of ethanol or methanol greater than shown above are not covered under the Warranty.

If your equipment will be used on an infrequent or intermittent basis please refer to the fuel section of the STORING YOUR ENGINE chapter (see page) for additional information regarding fuel deterioration.

⚠ WARNING

Gasoline is highly flammable and explosive and you can be burned or seriously injured when refueling.

- Stop the engine and keep heat sparks and flame away.
- Refuel only outdoors.
- Wipe up spills immediately.

NOTICE

Fuel can damage paint and some types of plastic. Be careful not to spill fuel when filling your fuel tank. Damage caused by spilled fuel is not covered under the Distributor's Limited Warranty.

Never use stale or contaminated gasoline or an oil gasoline mixture. Avoid getting dirt or water in the fuel tank.

With the engine stopped and on a level surface remove the fuel filler cap and check the fuel level. Refill the tank if the fuel level is low. Refer to the instructions provided with the equipment powered by this engine for refuelling.

Refuel in a well-ventilated area before starting the engine. If the engine has been running allow it to cool. Refuel carefully to avoid spilling fuel. It may be necessary to lower the fuel level depending on operating conditions. After refueling tighten the fuel tank cap securely.

Keep gasoline away from appliance pilot lights barbecues electric appliances power tools etc.


Spilled fuel is not only a fire hazard it causes environmental damage. Wipe up spills immediately.

ENGINE OIL

Oil is a major factor affecting performance and service life. Use 4-stroke automotive detergent oil.

Recommended Oil

Use 4-stroke motor oil that meets or exceeds the requirements for API service category S or later (or equivalent). Always check the API service label on the oil container to be sure it includes the letters S or later (or equivalent).



SAE 0W-30 or W-30 is recommended for general use. Use a full synthetic W-30 for starting operating temperatures between -20°F (-30°C) and -3°F (-20°C). Other viscosities shown in the chart may be used when the average temperature in your area is within the indicated range.

Oil Level Check

Check the engine oil level with the engine stopped and in a level position.


1. Start the engine and let it idle for 30 seconds. Stop the engine and wait for 3 minutes.

2. Remove the oil level dipstick and wipe it clean.

3. Fully insert the oil level dipstick then remove it to check the oil level.

4. If the oil level is low, remove the oil filler cap and fill with the recommended oil to the upper limit mark on the oil level dipstick.

5. Reinstall the oil level dipstick and oil filler cap.



NOTICE

Running the engine with a low oil level can cause engine damage. This type of damage is not covered by the Distributor's Limited Warranty.

The Oil Alert system (applicable types) will automatically stop the engine before the oil level falls below the safe limit. However, to avoid the inconvenience of an unexpected shutdown, always check the engine oil level before startup.


Oil Change

Drain the used oil when the engine is warm. Warm oil drains quickly and completely.

1. Place a suitable container below the engine to catch the used oil then remove the oil filler cap, drain bolt and sealing washer.

2. Allow the used oil to drain completely then reinstall the drain bolt and new sealing washer and tighten the drain bolt securely.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash, pour it on the ground or pour it down a drain.



3. With the engine in a level position, fill with the recommended oil to the upper limit mark on the oil level dipstick.

NOTICE

Running the engine with a low oil level can cause engine damage. This type of damage is not covered by the Distributor's Limited Warranty.

The Oil Alert system (applicable types) will automatically stop the engine before the oil level falls below the safe limit. However, to avoid the inconvenience of an unexpected shutdown, fill to the upper limit and check the oil level regularly.

4. Reinstall the oil filler cap and oil level dipstick securely.


OIL FILTER

Change

- Drain the engine oil and retighten the drain bolt securely.
- Remove the oil filter and drain the oil into a suitable container. Dispose the used oil and filter in a manner compatible with the environment.

NOTICE

Use an oil filter socket, rather than a strap wrench, to avoid striking and damaging the oil pressure switch.



3. Clean the filter mounting base and coat the seal of the new oil filter with clean engine oil.

NOTICE

Use only a Honda Genuine oil filter or a filter of equivalent quality specified for your model. Using the wrong filter, or a non-Honda filter which is not of equivalent quality, may cause engine damage.

4. Screw on the new oil filter by hand until the seal contacts the filter mounting base then use an oil filter socket tool to tighten the filter an additional 3/4 turn.

Oil filter tightening torque: 2 N·m (0.2 kgf·m, 9 lbf·ft)

- Refill the crankcase with the specified amount of the recommended oil (see page 10). Reinstall the oil filler cap and oil level dipstick.
6. Start the engine and check for leaks.
 - Stop the engine and check the oil level as described on page 10. If necessary, add oil to bring the oil level to the upper limit mark on the oil level dipstick.

AIR CLEANER

A dirty air cleaner will restrict air flow to the carburetor, reducing engine performance. If you operate the engine in very dusty areas, clean the air filter more often than specified in the MAINTENANCE SCHEDULE (see page 10).

NOTICE


Operating the engine without an air filter, or with a damaged air filter, will allow dirt to enter the engine, causing rapid engine wear. This type of damage is not covered by the Distributor's Limited Warranty.

Inspection

Remove the air cleaner cover and inspect the filter elements. Clean or replace dirty filter elements. Always replace damaged filter elements.

Cleaning


- Pull the air cleaner cover latch to the unlocked position and remove the cover.
 - Remove the wing nut from the paper filter element.
3. Remove the paper filter element and foam filter element from the air cleaner case.
 4. Remove the foam filter element from the paper filter element.



- Inspect both filter elements and replace them if they are damaged. Always replace the paper filter element at the scheduled interval (see page 10).


6. Clean the filter elements if they are to be reused.

Paper filter element Tap the filter element several times on a hard surface to remove dirt or blow with compressed air not exceeding 0 kPa (. kgf cm² 30 psi) through the filter element from the air cleaner case side.



Never try to brush off dirt brushing will force dirt into the fibers. Replace the paper filter element if it is excessively dirty.

Foam filter element Clean in warm soapy water, rinse and allow to dry thoroughly. Or clean in non-flammable solvent and allow to dry. Dip the filter element in clean engine oil then squeeze out all excess oil. The engine will smoke when started if too much oil is left in the foam.



Wipe dirt from the inside of the air cleaner body and cover using a moist rag. Be careful to prevent dirt from entering the air chamber that leads to the carburetor.

Place the foam filter element over the paper filter element and reinstall the assembled filter element. Be sure the packing is in place beneath the filter element. Tighten the locking nut securely.

9. Lock the air cleaner cover latch securely.

SPARK PLUG

Recommended Spark Plug FR F (NGK)

The recommended spark plug has the correct heat range for normal engine operating temperatures.

NOTICE


Incorrect spark plugs can cause engine damage.

If the engine has been running, let it cool before servicing the spark plugs.

For good performance, the spark plugs must be properly gapped and free of deposits.

Disconnect the spark plug caps and remove any dirt from around the spark plug area.

Remove the spark plugs with a 1/2-inch spark plug wrench.



3. Inspect the spark plugs. Replace them if damaged, badly fouled, if the sealing washer is in poor condition, or if the electrode is worn.

4. Measure the spark plug electrode gaps with a wire-type feeler gauge. Correct the gap if necessary by carefully bending the side electrode. The gap should be 0.6 – 0.8 mm (0.024 – 0.031 in).

Install the spark plug carefully by hand to avoid cross-threading.

6. After the spark plug is seated, tighten with a 1/2-inch spark plug wrench to compress the sealing washer.


When installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer.

When reinstalling the original spark plug, tighten 1/2 – 1 turn after the spark plug seats to compress the washer.

NOTICE

A loose spark plug can overheat and damage the engine. Overtightening the spark plug can damage the threads in the cylinder head.

Attach the spark plug caps to the spark plugs.



SPARK ARRESTER (applicable types)

In Europe and other countries here the machinery directive 2006/42/EC is enforced this cleaning should be done by your servicing dealer.

Your engine is not factory-equipped with a spark arrester. The spark arrester is optional part. In some areas it is illegal to operate an engine without a spark arrester. Check local laws and regulations. A spark arrester is available from authorized Honda servicing dealers.


The spark arrester must be serviced every 100 hours to keep it functioning as designed.

If the engine has been running the muffler will be hot. Allow it to cool before servicing the spark arrester.


Spark Arrester Cleaning & Inspection

- Remove the spark arrester

HIGH-MOUNT MUFFLER TYPE Remove the special screw from the muffler and remove the spark arrester.




SIDE-MOUNT MUFFLER TYPE Remove the 6 mm flange bolts from the muffler protector and remove the muffler protector. Remove the special screws from the spark arrester and remove the spark arrester from the muffler.



- Use a brush to remove carbon deposits from the spark arrester screen. Be careful to avoid damaging the screen.

The spark arrester must be free of breaks and holes. Replace the spark arrester if it is damaged.

HIGH-MOUNT MUFFLER TYPE **SIDE-MOUNT MUFFLER TYPE**



- Install the spark arrester and muffler protector in the reverse order of disassembly.

HELPFUL TIPS & SUGGESTIONS

STORING YOUR ENGINE

Storage Preparation

Proper storage preparation is essential for keeping your engine trouble-free and looking good. The following steps will help to keep rust and corrosion from impairing your engine's function and appearance and will make the engine easier to start when you use it again.

Cleaning

If the engine has been running allow it to cool for at least half an hour before cleaning. Clean all exterior surfaces touch up any damaged paint and coat other areas that may rust with a light film of oil.

NOTICE

Using a garden hose or pressure washing equipment can force water into the air cleaner or muffler opening. Water in the air cleaner will soak the air filter, and water that passes through the air filter or muffler can enter the cylinder, causing damage.

Fuel

NOTICE

Depending on the region where you operate your equipment, fuel formulations may deteriorate and oxidize rapidly. Fuel deterioration and oxidation can occur in as little as 30 days and may cause damage to the carburetor and/or fuel system. Please check with your servicing dealer for local storage recommendations.

Gasoline will oxidize and deteriorate in storage. Deteriorated gasoline will cause hard starting and it leaves gum deposits that clog the fuel system. If the gasoline in your engine deteriorates during storage you may need to have the carburetor and other fuel system components serviced or replaced.

The length of time that gasoline can be left in your fuel tank and carburetor without causing functional problems will vary with such factors as gasoline blend your storage temperatures and whether the fuel tank is partially or completely filled. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel deterioration problems may occur within a few months or even less if the gasoline is not fresh when you filled the fuel tank.

Fuel system damage or engine performance problems resulting from neglected storage preparation are not covered under the Distributor's Limited Warranty.

You can extend fuel storage life by adding a gasoline stabilizer that is formulated for that purpose or you can avoid fuel deterioration problems by draining the fuel tank and carburetor.

Adding a Gasoline Stabilizer to Extend Fuel Storage Life

When adding a gasoline stabilizer fill the fuel tank with fresh gasoline. If only partially filled air in the tank will promote fuel deterioration during storage. If you keep a container of gasoline for refueling be sure that it contains only fresh gasoline.

- Add gasoline stabilizer following the manufacturer's instructions.
- After adding a gasoline stabilizer run the engine outdoors for 10 minutes to be sure that treated gasoline has replaced the untreated gasoline in the carburetor.

- Stop the engine and if the fuel tank is equipped with a fuel valve move the fuel valve to the CLOSED or OFF position.

Draining the Fuel Tank and Carburetor


WARNING

Gasoline is highly flammable and explosive and you can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

1. Disconnect the fuel line to the engine and drain the fuel tank into an approved gasoline container. If the fuel tank is equipped with a valve, turn the fuel valve to the OPEN or ON position to enable draining. After draining is completed, reconnect the fuel line.

2. Loosen the carburetor drain screw and drain the carburetor into an approved gasoline container. After draining is completed, tighten the carburetor drain screw.



Engine Oil

- 1. Change the engine oil (see page 10).
- 2. Remove the spark plugs (see page 10).
- 3. Pour 100 cm³ (100 cc, 4 teaspoons) of clean engine oil into each cylinder.
- 4. Turn the engine for a few seconds by turning the engine switch to the START position to distribute the oil in the cylinders.
- 5. Reinstall the spark plugs.

Storage Precautions

If your engine will be stored with gasoline in the fuel tank and carburetor, it is important to reduce the hazard of gasoline vapor ignition. Select a well-ventilated storage area away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area where spark-producing electric motor or other power tools are operated.

If possible, avoid storage areas with high humidity because that promotes rust and corrosion.

Keep the engine level in storage. Tilting can cause fuel or oil leakage.

Unless all fuel has been drained from the fuel tank, leave the fuel valve in the CLOSED or OFF position to reduce the possibility of fuel leakage.

With the engine and exhaust system cool, cover the engine to keep out dust. A hot engine and exhaust system can ignite or melt some materials. Do not use sheet plastic as a dust cover. A nonporous cover will trap moisture around the engine, promoting rust and corrosion.

If installed, remove the battery and store it in a cool, dry place. Recharge the battery once a month while the engine is in storage. This will help to extend the service life of the battery.

Removal from Storage

Check your engine as described in the *BEFORE OPERATION CHECKS* section of this manual (see page 4).

If the fuel has been drained during storage preparation, fill the tank with fresh gasoline. If you keep a container of gasoline for refueling, be sure it contains only fresh gasoline. Gasoline oxidizes and deteriorates over time, causing hard starting.

If the cylinders were coated with oil during storage preparation, the engine may smoke briefly at startup. This is normal.

TRANSPORTING

If the engine has been running, allow it to cool for at least 10 minutes before loading the engine-powered equipment on the transport vehicle. A hot engine and exhaust system can burn you and can ignite some materials.

Keep the engine level when transporting to reduce the possibility of fuel leakage. If the fuel tank is equipped with a fuel valve, move the fuel valve lever to the CLOSED or OFF position.

TAKING CARE OF UNEXPECTED PROBLEMS


ENGINE WILL NOT START	Possible Cause	Correction
. Electric starting Check battery and fuse.	Battery discharged.	Recharge battery.
	Fuse burnt out.	Replace fuse.
. Check control positions.	Fuel valve CLOSED or OFF. (If equipped)	Move lever to OPEN or ON position.
	Choke OPEN.	Move knob to CLOSED position unless the engine is warm (p. 4).
	Engine switch OFF.	Turn engine switch to ON position (p.).
3. Check engine oil level.	Engine oil level low (Oil Alert stops engine).	Fill with the recommended oil to the proper level (p.).
4. Check fuel.	Out of fuel.	Refuel (p.).
	Stale fuel engine stored without treating or draining gasoline or refueled with stale gasoline.	Drain fuel tank and carburetor (p.). Refuel with fresh gasoline (p.).
. Remove and inspect spark plugs.	Spark plugs faulty fouled or improperly gapped.	Gap or replace spark plugs (p. 0).
	Spark plugs wet with fuel (flooded engine).	Dry and reinstall spark plugs (p. 0). Start engine with throttle lever in MAX. position (p. 6).
6. Take engine to an authorized Honda servicing dealer or refer to shop manual.	Fuel filter restricted carburetor malfunction ignition malfunction valves stuck etc.	Replace or repair faulty components as necessary.

ENGINE LACKS POWER	Possible Cause	Correction
. Check air filter.	Filter element(s) restricted.	Clean or replace filter element(s) (p. 9).
. Check fuel.	Stale fuel engine stored without treating or draining gasoline or refueled with stale gasoline.	Drain fuel tank and carburetor (p.). Refuel with fresh gasoline (p.).
3. Take engine to an authorized Honda servicing dealer or refer to shop manual.	Fuel filter restricted carburetor malfunction ignition malfunction valves stuck etc.	Replace or repair faulty components as necessary.

FUSE REPLACEMENT


The electric starter relay circuit and battery charging circuit are protected by a 30-ampere fuse. If the fuse burns out the electric starter will not operate.

- . Disconnect the wire connector and remove the wire harnesses from the wire harness band.



- . Remove the 6 × mm special screw from the rear cover of the engine switch box and remove the rear cover.

3. Remove the fuse cover and inspect the fuse.



If the fuse is burnt out remove the fuse cover then pull out and discard the burnt-out fuse. Install a new 30-ampere fuse and reinstall the fuse cover.

NOTICE

Never use a fuse with a rating greater than 30 amperes. Serious damage to the electrical system or a fire could result.


4. Reinstall the rear cover. Install the 6 × mm special screw and tighten it securely.

Frequent fuse failure usually indicates a short circuit or an overload in the electrical system. If the fuse burns out frequently take the engine to a Honda servicing dealer for repair.

TECHNICAL INFORMATION

Serial Number Location

Record the engine serial number type and purchase date in the spaces below. You will need this information when ordering parts and when making technical or warranty inquiries.



Engine serial number _____

Engine type _____

Date Purchased _____

Battery Connections for Electric Starter

Recommended Battery

GX630	V-36 Ah
GX660	
GX690	

Be careful not to connect the battery in reverse polarity as this will short circuit the battery charging system. Always connect the positive (+) battery cable to the battery terminal before connecting the negative (-) battery cable so your tools cannot cause a short circuit if they touch a grounded part while tightening the positive (+) battery cable end.


⚠ WARNING

A battery can explode if you do not follow the correct procedure seriously injuring anyone nearby.

Keep all sparks open flames and smoking materials away from the battery.

WARNING Battery posts terminals and related accessories contain lead and lead compounds. Wash hands after handling.


- 1. Connect the battery positive (+) cable to the starter solenoid terminal as shown.
- 2. Connect the battery negative (-) cable to an engine mounting bolt frame bolt or other good engine ground connection.
- 3. Connect the battery positive (+) cable to the battery positive (+) terminal as shown.
- 4. Connect the battery negative (-) cable to the battery negative (-) terminal as shown.
- 5. Coat the terminals and cable ends with grease.




Remote Control Linkage

The throttle and choke control levers are provided with holes for optional cable attachment. The following illustrations show installation examples for a solid wire cable and for a flexible braided wire cable.

RIGHT SIDE CONTROL




LEFT SIDE CONTROL




WIRE HOLDER

• For Throttle Cable



• For Choke Cable



Carburetor Modifications for High Altitude Operation

At high altitude the standard carburetor air-fuel mixture will be too rich. Performance will decrease and fuel consumption will increase. A very rich mixture will also foul the spark plug and cause hard starting. Operation at an altitude that differs from that at which this engine is certified for extended periods of time may increase emissions.

High altitude performance can be improved by specific modifications to the carburetor. If you always operate your engine at altitudes above 1000 meters (3000 feet) have your servicing dealer perform this carburetor modification. This engine when operated at high altitude with the carburetor modifications for high altitude use will meet each emission standard throughout its useful life.

Even with carburetor modification engine horsepower will decrease about 3% for each 300 meter (1000 foot) increase in altitude. The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

NOTICE

When the carburetor has been modified for high altitude operation, the air-fuel mixture will be too lean for low altitude use. Operation at altitudes below 1,500 meters (5,000 feet) with a modified carburetor may cause the engine to overheat and result in serious engine damage. For use at low altitudes, have your servicing dealer return the carburetor to original factory specifications.

Emission Control System Information

Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way but it is toxic.

Honda utilizes appropriate air/fuel ratios and other emissions control systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons. Additionally, Honda fuel systems utilize components and control technologies to reduce evaporative emissions.

The U.S. California Clean Air Act and Environment Canada, EPA, California, and Canadian regulations require all manufacturers to furnish written instructions describing the operation and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your Honda engine within the emission standards.

Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Among those acts that constitute tampering are

- Removal or alteration of any part of the intake, fuel, or exhaust systems.
- Altering or defeating the governor linkage or speed-adjusting mechanism to cause the engine to operate outside its design parameters.

Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your servicing dealer.

- Hard starting or stalling after starting.
- Rough idle.
- Misfiring or backfiring under load.
- Afterburning (backfiring).
- Black exhaust smoke or high fuel consumption.

Replacement Parts

The emission control systems on your Honda engine are designed, built, and certified to conform with EPA, California (models certified for sale in California), and Canadian emission regulations. We recommend the use of Honda Genuine parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance. The use of replacement parts that are not of the original design and quality may impair the effectiveness of your emission control system.

A manufacturer of an aftermarket part assumes the responsibility that the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.

Maintenance

Follow the maintenance schedule on page . Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load or high-temperature operation or use in unusually wet or dusty conditions will require more frequent service.

Air Index
(Models certified for sale in California)

An Air Index Information label is applied to engines certified to an emission durability time period in accordance with the requirements of the California Air Resources Board.

The bar graph is intended to provide you our customer the ability to compare the emissions performance of available engines. The lower the Air Index the less pollution.

The durability description is intended to provide you with information relating to the engine's emission durability period. The descriptive term indicates the useful life period for the engine's emission control system. See your *Emission Control System Warranty* for additional information.

Descriptive Term	Applicable to Emissions Durability Period
Moderate	0 hours (0— 0 cc inclusive) hours (greater than 0 cc)
Intermediate	hours (0— 0 cc inclusive) 0 hours (greater than 0 cc)
Extended	300 hours (0— 0 cc inclusive) 00 hours (greater than 0 cc) 000 hours (cc and greater)

Specifications

GX630 (AF-Type)

Length × Width × Height	40 × 4 0 × 43 mm (.9 × 6. × . in)
Dry mass eight	44.4 kg (9 .9 lbs)
Engine type	4-stroke overhead valve cylinders (90 V-T in)
Displacement Bore × Stroke	6 .0 cm ³ (4 .9 cu-in) .0 × .0 mm (3.0 × . 3 in)
Net po er (in accordance ith SAE 349*)	. kW (. PS 0. bhp) at 3 600 rpm
Max. Net tor ue (in accordance ith SAE 349*)	4 .3 N·m (4.93 kgf·m 3 .6 lbf·ft) at 00 rpm
Engine oil capacity	Without oil filter replacement . L (.6 US t .3 Imp t) With oil filter replacement . L (. US t . Imp t)
Cooling system	Forced air
Ignition system	CDI type magneto ignition
PTO shaft rotation	Counterclock ise

GX660 (TAF-Type)

Length × Width × Height	4 9 × 4 0 × 43 mm (6.9 × . × . in)
Dry mass eight	4 .3 kg (99.9 lbs)
Engine type	4-stroke overhead valve cylinders (90 V-T in)
Displacement Bore × Stroke	6 .0 cm ³ (4 .9 cu-in) .0 × .0 mm (3.0 × . 3 in)
Net po er (in accordance ith SAE 349*)	6.0 kW (. PS . bhp) at 3 600 rpm
Max. Net tor ue (in accordance ith SAE 349*)	4 .3 N·m (4.93 kgf·m 3 .6 lbf·ft) at 00 rpm
Engine oil capacity	Without oil filter replacement . L (.6 US t .3 Imp t) With oil filter replacement . L (. US t . Imp t)
Cooling system	Forced air
Ignition system	CDI type magneto ignition
PTO shaft rotation	Counterclock ise

GX690 (TAF-Type)

Length × Width × Height	4 9 × 4 0 × 43 mm (6.9 × . × . in)
Dry mass eight	4 .3 kg (99.9 lbs)
Engine type	4-stroke overhead valve cylinders (90 V-T in)
Displacement Bore × Stroke	6 .0 cm ³ (4 .9 cu-in) .0 × .0 mm (3.0 × . 3 in)
Net po er (in accordance ith SAE 349*)	6. kW (.4 PS . bhp) at 3 600 rpm
Max. Net tor ue (in accordance ith SAE 349*)	4 .3 N·m (4.93 kgf·m 3 .6 lbf·ft) at 00 rpm
Engine oil capacity	Without oil filter replacement . L (.6 US t .3 Imp t) With oil filter replacement . L (. US t . Imp t)
Cooling system	Forced air
Ignition system	CDI type magneto ignition
PTO shaft rotation	Counterclock ise

*The po er rating of the engine indicated in this document is the net po er output tested on a production engine for the engine model and measured in accordance ith SAE 349 at 3 600 rpm (Net Po er) and at 00 rpm (Max. Net Tor ue). Mass production engines may vary from this value. Actual po er output for the engine installed in the final machine ill vary depending on numerous factors including the operating speed of the engine in application environmental conditions maintenance and other variables.

Tuneup Specifications GX630 660 690


ITEM	SPECIFICATION	MAINTENANCE
Spark plug gap	0. —0. mm (0.0 —0.03 in)	Refer to page 0
Idle speed	400 ± 0 rpm	See your authorized Honda dealer
Valve clearance (cold)	IN 0.0 ± 0.0 mm EX 0. 0 ± 0.0 mm	See your authorized Honda dealer
Other specifications	No other adjustments needed.	

uick Reference Information


Fuel	Unleaded gasoline (Refer to page).	
	U. S.	Pump octane rating 6 or higher
	Except U. S.	Research octane rating 9 or higher Pump octane rating 6 or higher
Engine oil	SAE 0W-30 API S or later for general use. Refer to page .	
Spark plug	FR F (NGK)	
Maintenance	Before each use	
	• Check engine oil level. Refer to page . • Check air filter. Refer to page 9.	
	First 0 hours	
	• Change engine oil. Refer to page .	
	Subse uent	
	Refer to the maintenance schedule on page .	

Wiring Diagrams


2.7 A Charge Coil and With Control Box Type




17 A Charge Coil and With Control Box Type



2.7 A Charge Coil and Without Control Box Type



17 A Charge Coil and Without Control Box Type



CONSUMER INFORMATION

WARRANTY AND DISTRIBUTOR DEALER LOCATOR INFORMATION

United States Puerto Rico and U.S. Virgin Islands
Visit our website [.honda-engines.com](http://www.honda-engines.com)

Canada
Call () 9HONDA9
or visit our website [.honda.ca](http://www.honda.ca)

For European Area
Visit our website [http .honda-engines-eu.com](http://www.honda-engines-eu.com)

Australia
Call (03) 9 0 34
or visit our website [.hondampe.com.au](http://www.hondampe.com.au)

CUSTOMER SERVICE INFORMATION

Servicing dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction please discuss it with the dealership's management. The Service Manager General Manager or Owner can help. Almost all problems are solved in this way.

United States Puerto Rico and U.S. Virgin Islands

If you are dissatisfied with the decision made by the dealership's management contact the Honda Regional Engine Distributor for your area.

If you are still dissatisfied after speaking with the Regional Engine Distributor you may contact the Honda Office as shown.

All Other Areas

If you are dissatisfied with the decision made by the dealership's management contact the Honda Office as shown.

《Honda's Office》

When you write or call please provide this information

- Equipment manufacturer's name and model number that the engine is mounted on
- Engine model serial number and type (see page 4)
- Name of dealer who sold the engine to you
- Name address and contact person of the dealer who services your engine
- Date of purchase
- Your name address and telephone number
- A detailed description of the problem

United States Puerto Rico and U.S. Virgin Islands
American Honda Motor Co. Inc.
Power Equipment Division
Customer Relations Office
4900 Marconi Drive
Alpharetta GA 3000 - 4

Or telephone () 01 49 -6400 30 am - 00 pm ET

Canada
Honda Canada Inc.
Please visit [.honda.ca](http://www.honda.ca)
for address information

Telephone () 9HONDA9 Toll free
() 946-63 9
Facsimile () 939-0909 Toll free

Australia
Honda Australia Motorcycle and Power Equipment Pty. Ltd.
94—96 Hume Highway
Campbellfield Victoria 306

Telephone (03) 9 0
Facsimile (03) 9 0 33

For European Area
Honda Europe NV.
European Engine Center

[http .honda-engines-eu.com](http://www.honda-engines-eu.com)

All Other Areas

Please contact the Honda distributor in your area for assistance.

HONDA
The Power of Dreams